


Ex9MD2 / EX9M2 SD (DC)




Circuit breaker  
Jistič  
Istič  
Wyłącznik kompaktowy  
Intrupator automat in carcasa turnata  
Leistungsschalter  
Disjoncteur  
Автоматический выключатель  
Автоматичен прекъсвач  
Prekidač  
Megszakítók  
Automatinis jungiklis  
Автоматичний вимикач

Switch disconnector  
Odpínač  
Odpínač  
Rozłącznik kompaktowy  
Comutator de separare  
Lastennschalter  
Interrupteurs-sectionneur  
Выключатель нагрузки  
Изключатели  
Sklopka- rastavljač  
Szakaszolókapcsolók  
Galios išjungiklis  
Вимикач навантаження


AP&EU

NOARK

A









B







mm

C

|   |       | N  |    |    |
|---|-------|----|----|----|
|   |       | 2P | 3P | 4P |
|  | M5×70 | 2  | 4  | 4  |
|  | 5     | 2  | 4  | 4  |
|  | 5     | 2  | 4  | 4  |
|  | M5    | 2  | 4  | 4  |
|  |       | 2  | 4  | 6  |
|  |       | 0  | 1  | 2  |

| mm  | mm  |
|---|---|
|  |  |
|  |  |


Mounting instructions  
Montážní návod  
Montážne inštrukcie  
Instrukcja montażu  
Instrucțiuni de asamblare  
Montageanweisung  
Instructions de montage  
Инструкция по монтажу  
Monteringsanvisning  
Istruzioni di montaggio  
Instrucciones de montaje  
Összeszerelési útmutató

Asennusohjeita  
Montage-instructies  
Instrucões de montagem  
Navodila za montažo  
Οδηγίες Εγκατάστασης  
Инструкции за инсталиране  
Monteringsvejledningen  
Montažu upute  
Surinkimo instrukcijos  
Instalēšanas instrukcijas  
Скупштина упутство  
Paigaldusjuhendid


Caution: Installation by electricians only  
Varování: Montáž pouze osobou s elektrotech, kvalifikací  
Varovanie: Montáž iba osobou s elektrotech, kvalifikáciou  
Uwaga: Montaż tylko przez uprawnionych instalatorów  
Atenție: Instalare numai de către electricieni  
Vorsicht: Montagenur durch Elektrofachkräfte  
Attention: Montage uniquement par un électricien  
Осторожно: Монтаж только электрика

NOARK


D Test




E




F




A:




1



2 3P




2 4P



mm


G




1

2


$I_R=0.8\sim 0.9I_n$   
 $I_L=5\sim 10I_n$




3




B:




3 3P




3 4P



4 3P




4 4P





mm

H






mm

I



J



Printed with environment-friendly paper  
 Noark Electric Europe s.r.o., Sezemicka 2757/2, Prague, Czech Rep.

Copyright Noark. All Rights Reserved

www.noark-electric.eu

**NOARK**  
 Z9MD2201711AP/EU